

Korniche Bi-folding door guide to operation and maintenance



Components



D handle



Bottom mullion roller



Magnetic catch



Yale 3 star lock barrel & key



Top guide hinge



Top mullion guide



Main hinge



Shoot bolt handle and key



Bottom roller hinge



Trickle vents 2500mm² airflow per vent




Opening the doors

Fold back the master sash (door panel) fully until magnets engage



Push the sash stack along the track until stacked together








Closing the doors

Pull the stack along the track until the D handle can be reached.



Using the D handle whilst holding the doors shut, rotate the shootbolt handle down into the closed position.



Return the master sash into a closed position.



Operating the lever handle

To open

To unlock, rotate the Yale key and then depress handle to dis-engage locks



To open. Keep handle depressed. Push/pull to open door



To lock

To lock, pull handle upwards to engage locks. Rotate Yale key to



Operating the shoot bolt handle

To unlock the shootbolt handle, insert and turn the black Korniche shootbolt key half a turn. Remove the key.



2 Gently lift the handle away from the door.

Rotate the handle whilst holding as shown below to disengage shootbolts. To lock the handle reverse the procedure.







Glass

External dirt can be removed with a soap and water solution. Cleaning solutions used should not be allowed to run down on other surfaces. General household glass cleaners may be used with a soft cloth. Do not use a jet wash.

Panels & Door Frame

Door frames and panels can be cleaned with a soap and water solution. Avoid all solvent based or abrasive cleaners. Take care not to disturb rubber seals and gaskets. Do not use a jet wash.

Tracks & Rollers

Tracks must remain clean and clear of debris at all times. Dust and dirt can build up on the rollers and tracks and affect the smooth running of the door. Tracks can be cleaned by using a soft bristled brush and vacuum with a thin nozzle attachment.

It is recommended every 6 months to thoroughly clean and dry all upper and lower rollers and all hinges.



General maintenance

Hardware fittings

riai uwai e iittii iys

Applying a small amount of light lubricant oil to both key hole and key will ensure ease of operation and avoid sticking.

Handles

No general maintenance is required for handles. Clean with a non-abrasive cloth and non-solvent general household cleaner



In the unlikely event that your cylinder is snapped under attack due to a forced break-in, YALE will give you £1,000 compensation for any distress and inconvenience caused, that's how confident we are in the YALE lock barrel product.

How does it work? Simply register your guarantee online at help.yale.co.uk within 30 days of purchase to ensure you are covered for five years





10 Year warranty

Korniche products are built to last, but for extra peace of mind they are covered by a comprehensive warranty from the manufacturer. The warranty provided with the products is valid from the day of delivery and importantly extends from the installer to the owner of the property where the products are originally fitted. During the Warranty period, which for domestic non marine environments is 10 years, the goods shall conform to the original specification and be free from material defects in design, material, and workmanship. Claims on the Warranty should be made through the installing company or business from which the products were purchased, but in the event that the company cannot be contacted, your product manufacturer will still honour any covered parts failures with replacements. Details on the Warranty Periods and the full T&C can be found on the Korniche website. Scan the QR code below to view.





korniche.co.uk